




Floorlight Jupiter Manual Instruction



1.) Loose the 2 screws, left and right from the mounting bracket



2.) Adjust the bracket to 90°, then tight the screw at both side.



3.) Connecting the power supply wiring according to Blue, Green & Brown.



Note: Specification are subject to change without prior notice



HI-BEAM™ Lighting

